
DuroZone

35138 MOTOR REPLACEMENT INSTRUCTIONS

ROUND & MULTISIZE DAMPERS


FOR (MS) MULTISIZE & STANDARD (RD) ROUND DAMPERS

- 1- Prior to replacing your damper motor, be sure to turn off all incoming electrical power.
- 2- Disconnect all wires from the current motor, noting the appropriate terminal numbers.
- 3- Remove and discard the existing damper motor and screws.
- 4- If the **Terminal Identification Label** currently on the damper does not appear as shown below at left, place the enclosed **Terminal Identification Label** directly over the existing one.
- 5- To mount the Replacement Motor (if different from the existing motor)
 - (a) For (MS) MULTISIZE DAMPERS: cutout the indicated hole on the Face Plate Sticker and place it onto the Face Plate as shown.
 - (b) For (RD) ROUND DAMPERS: position the Replacement Motor and secure it with the supplied Small S/M Screw through the Bracket and the Large Screws through the Replacement Motor as shown below and re-attach the wires as per the Terminal Identification Label.



FOR (TS) TRUE SIZE ROUND DAMPERS

- 1- Prior to replacing your damper motor, be sure to turn off all incoming electrical power.
- 2- Disconnect all wires from the current motor, noting the appropriate terminal numbers.
- 3- Loosen the Mounting Nut and Set Screw #2; remove and discard the existing damper motor assembly.
- 4- Prior to assembling the **Replacement Motor**, ensure the **Motor Shaft** is in the postion shown below at left (open/green position) and secure the **Coupling** to the **Motor Shaft** as per that view; once set, tighten the **Set Screw #1**.
- 5- NOTE: Prior to attaching the Mounting Plate, the Bracket may need to be removed to secure the Replacement Motor Assy properly. Secure the supplied Mounting Plate to the Replacement Motor as shown below at center using the two Large Screws supplied.
- 6- Install the Replacement Motor Assy onto the Blade Shaft and Stud; secure it with the Set Screw #2 and Mounting Nut. Re-connect the wires as before.



Duro Dyne East - Bay Shore, NY 11706	-	Phone:631-249-9000 - Fax:631-249-8346
Duro Dyne Midwest - Fairfield, OH 45011	-	Phone:513-870-6000 - Fax:513-870-6005
Duro Dyne West - Fontana, CA 92337	-	Phone:562-926-1774 - Fax:562-926-5778
Duro Dyne Canada - Lachine, QC Canada	-	Phone:514-422-9760 - Fax:514-636-0328

31035138/A308-01-02/Rev-C(ECR-1019)/11-13-15 ©2008 Duro Dyne Corp. Printed in USA 11/15