



# Machinery Spare Parts List

Effective May 1st, 2018



## DURO DYNE MACHINERY SPARE PARTS LIST

PART #	DESCRIPTION
5074	Pumpurr TSL Lubricating Oil - Pint
5075	Pumpurr TSL Lubricating Oil - Quart
5079	Pumpurr Gun & Hose Kit
5081	Pumpurr 25ft Additional Hose Only
5083	Pumpurr Needle Nose Complete Assembly
5084	Pumpurr Replacement Needle Only
5085	Pumpurr Replacement Needle w/ Brass Fittings
5086	Pumpurr Standard Replacement Nozzle
5089	Pumpurr Gun Only
5120	CAG Liner Adhesive Gun Only
5144	SSFU Black Fluid Hose 15ft w/Fittings
5145	SSFU Red Air Hose 15ft w/Fittings
5146	SSFU Black Fluid Hose 25ft w/Fittings
5147	SSFU Red Air Hose 25ft w/Fittings
9012	S1 6in Long Arms w/MT3 Tips
9013	S2 12in Long Arms w/MT3 Tips
9014	S3 18in Long Arms w/MT3 Tips
9015	A1 6in Long Arms w/MT3 Tips
9016	A2 15in Long Arms w/MT3 Tips
9017	A3 18in Long Arms w/MT3 Tips
9018	MT3 Spotwelder Standard Replacement Tips (Threaded)
9019	MT1 Spotwelder Water Cooled Tip (Taper Fit)
9020	MT2 Spotwelder Water Cooled Tip (Taper Fit)
9022	S2W 12in Long Water Cooled Arms w/ MT1 Tips
9023	S3W 18in Long Water Cooled Arms w/ MT1 Tips
9026	A2W 15in Long Water Cooled Arms w/ MT1 Tips
9027	A3W 18in Long Water Cooled Arms w/ MT1 Tips
9040	BW/SP Control Spring 1010
9050	BW/SP Bottom Body 1021
9065	BW Channel
9066	BW Frame Carrying Handle
9088	GDW Upper Tip Holder
9089	GDW Lower Tip Holder
9090	GDW Air Solenoid
9105	GDW Copper Leaf Assembly
9112	GDW Air Sleeve Valve
9125	MT4 Spotwelder Offset Replacement Tips
9216	TSP/TBW Nose Piece
9217	TSP/TBW Lower Arm Mounting
9218	TSP Handle - Straight
9219	TBW Handle - Bent
9220	TSP/TBW Switch Mount Bracket
9221	TSP/TBW Handle Spring
9222	TSP/TBW Actuator Spring
9223	TSP/TBW Nylon Actuator
9224	TSP/TBW Micro Switch
9225	TSP/TBW Switch Control Screw
9226	TSP1 Weld Timer 110 Volt
9227	TSP/TBW Potentiometer-OLD STYLE
9230	TSP Line Cord 110 Volt
9231	TSP Line Cord 220 Volt

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
9232	TBW HI/LO Switch
9238	TSP/TBW Pivot Bolt
9239	TSP/TBW Timer 220 Volt
9240	TSP/TBW Line Cord Retainer
9241	TBW Nylon Actuator
9246	TSP/TBW potentiometer-new
9247	TSP 110Timer-Pot Assy Kit
9248	TSP/TBW 220Timer-Pot Assy Kit
17049	Male Camlock
17078	FG SQE2 Repair Kit
17079	Vibrator Foot
17084	Air Hose 3/8in Natural
17086	FG Vibrator Caution Cover (Yellow)
17132	AB 110V Vibrator Repl Coil
17133	FG/RH/MH 220V Vib Repl Coil
17134	Universal Short Shaft Extension Kit
17135	FG/RH Lift Kit
17136	FG Original Track Sensor Replacement Kit
17137	RH Original Track Sensor Replacement Kit
17138	FG Delay/Relay Timer
17140	FG Weld Activator Only - New
17141	AB4/5 Control Box w/Reed Switches
17142	AB4/5 Control Box Cover
17143	AB4/5 Drive Timer W/Resistor
17144	AB4/5 Feed Timer W/Resistor
17146	AB4/5 Vibrator Receptacle
17148	110Volt Vibrator Speed Control
17151	AB4/5 24 VoltTransformer
17153	AB4/5 1ST Pulse Relay Base
17156	AB4/5 Line Cord
17157	AB4/5 Feed/Track Assembly
17164	AB4/5 Track Casting Only
17167	AB4/5 Drive Cylinder (D-23046-A-3)
17168	AB4/5 Drive Cylinder Bracket (D8316)
17169	AB4/5 Drive Quick Exhaust
17170	AB4/5 Drive Valve
17171	AB4/5 Dwell Solenoid/Regulator
17172	AB4/5 Drive Cylinder Press Regulator
17175	AB4/5 Feed Solenoid
17176	AB4/5 Vibrator Base 110 Volt
17184	AB4/5 Lower Mandrel
17185	AB4/5 Magnetic Drive
17187	AB4/5 Feed Relay Timer
17189	UWP FG/RH Upper Weld Replacement Plates 5/pk
17190	LWP FG/RH Lower Weld Tip Replacement Plates 5/pk
17191	UWT FG/RH Upper Weld Tip Assembly
17192	LWT FG/RH Lower Weld Tip Assembly
17195	AB4/5 Front Cover
17196	AB4/5 Feed Cover
17197	AB4/5 Interlock Timer
17198	FG/RH/FGMH Track Casting Spacers & Set Screws Set

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
17200	TUWP FG/RH Target Upper Replacement Plates 5/pk
17201	Vibrator Bowl Springs (6/Pk)
17202	FG Vibrator Spring Spacers(6pcs)
17204	RH Cable Support Arm
17205	RH PP3 Power Pack
17208	RH PP3 Terminal Block
17209	FG/RH Line Cord w/Strain Relief
17210	RH Line Cord STR-REL
17212	RH Power Pack Component Tray
17213	RH Power Pack Insulator
17214	RH Control Console
17218	RH Voltmeter
17220	RH TRolley
17221	RH Trolley Tray
17222	RH Terminal Block
17223	RH Relay Mounting Bracket
17224	RH Relay Base
17230	RH Air Brake
17231	RH Dwell Cylinder (D19883-A-5)
17235	RH Anti Rotation Bar
17236	MACH Cylinder Bracket
17239	RH/RH MACH Feed Solenoid
17240	RH/RH MACH Dwell Solenoid
17247	RH Vibrator Base
17253	RH Sensor Block
17257	FG/RH Vibrator Support Casting
17260	RH/MACH I/II Upper Track Casting
17261	RH Lower Track Casting
17262	RH Clip Pin Release Spring
17263	RH Clip Pin Release
17264	RH/MACH I/II Upper Track Siderails
17265	MACH I/II Low Track Siderails
17266	RH Feed Channel
17269	RH Feed Cylinder Bracket (D8315)
17273	RH Feed Cylinder Cover
17274	RH Trolley Mounting Plate
17275	RH Bearing Mounting Plate
17276	RH Upper Bearing
17277	RH Lower Bearing
17278	RH Steel Tracks
17279	RH Upper Copper Insulator
17280	RH Female Camlock
17281	RH Hand Gun & Ground Set
17283	RH Trigger Actuator Assembly
17284	RH Micro Switch
17285	RH Actuator Switch Assembly
17286	RH Actuator Mount Plate
17287	RH Actuator Swivel Mount
17288	RH Male Switch Plug
17289	RH Locking Knob
17290	RH Brake Pad

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
17291	RH Bumper Stop
17292	RH Coiled Air Hose
17293	RH/FPP 24 Volt Power/Switch Cord
17294	RH Weld Cable
17300	FG PP2 Power Pack
17305	FG 24 Volt Receptacle
17307	FG Voltmeter
17308	FG Pilot Light
17309	FG ON/OFF Switch
17313	FG Terminal Block
17315	FG Component Module
17316	FG Feed Solenoid
17317	Feed Speed Control
17318	Feed Timer W/Resistor
17319	Dwell Timer
17320	Dwell Potentiometer
17321	FG Dwell Solenoid
17322	FG COMP Module Terminal Block
17323	FG First Pulse Short Cycle Relay
17325	FG Pressure Switch
17326	FG Exhaust Muffler
17327	Switch Receptacle
17328	FG 24 Volt Component Line
17329	FG Vibrator Fuse
17330	Vibrator Fuse Holder
17332	FG Vibrator Sense Switch
17333	FG/RH Vibrator Speed Control
17334	FG Vibrator/ASVC ON/OFF Switch
17336	FG Male Reed Switch Plug
17337	FG Female Reed Switch Plug
17338	FG Vibrator Mounting Plate
17339	FG Vibrator Base
17340	Standard 1in Vibrator Bowl FG/RH/FGMH
17341	FG Vibrator Coil/Armature (DD TYPE)
17342	FG Vibrator Base Springs -9/PK
17343	FG Feed/Dwell Tracking Assembly
17344	FG Track Casting Assembly
17345	FG Track Casting Only
17346	FG Track Side Rails
17347	FG/FPP Feed Channel
17348	Feed Channel Plate
17349	FG Feed Track Sensor
17350	FG Needle Valve
17351	FG Slide Pusher w/Pawl
17355	FG Quick Exhaust Valve
17356	FG Adjustment Muffler
17357	FG Upper Insulated Bracket
17358	FG Lower Insulated Bracket
17359	UNIV Bracket Insulator w/Screw
17360	FG Weld Cable (4ft Throat)
17361	FG Weld Cable Retainer

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
17362	FG/FPP Dwell Cylinder (D19883-A-4)
17363	FG Dwell Reed Switch
17364	FG Feed Cylinder (MRS-092-DZ)
17367	FG Transformer Side Covers (2)
17368	Vibrator 2in Bowl FG/RH/FGMH
17369	FG/FPP Power Supply Bar
17370	FG Dwell Cover
17371	FG Feed Cover
17372	FG Foot Switch w/Guard
17373	FG Foot Switch Only
17375	FG Component Tray Top Cover
17376	FG Mandrel
17377	FG Regulator Assembly
17378	FG Regulator Bracket
17381	FG Hand Gun & Ground Set
17382	FG Weld Cable (5ft Throat)
17383	FG Male Switch Cable Plug
17385	A. Potentiometer Knob
17386	RH Trolley Cover
17387	RH Power Pack Cover
17390	Dwell Cylinder Mounting Nut FG/RH/FGMH
17391	RH Actuator Swivel Bolt
17392	RH Clip Pin Release Bolt
17393	RH Locking Knob Spring
17395	RH Lower Ground Bar
17396	RH Trolley w/Feed Assembly
18020	FPP Track Sensor
18021	FPP Dwell Solenoid
18022	FPP Feed Solenoid
18023	FPP Front Weld Cable
18024	FPP Rear Ground Cable
18025	FPP Feed Cylinder Guard
18026	FPP Dwell Cylinder Guard
18027	FPP Weld Head Assembly
18028	MH/FPP 3amp Fuse
18029	HSMH/FPP 24 Volt Transformer
18051	FG/RH Function Display Board
18052	MACH II 208/220 Buck & Boost Transformer
18053	FG/RH Digital Display Kit-New
18054	MACH Vibrator Control Relay Board Retrofit Kit
18055	FG MACH Upper Dwell Cylinder Bracket
18056	RH MACH Locking Knob
18057	MACH I & II Vibrator Base
18063	MACHI/II Vib Line Cord Kit
18064	RH MACH II Rotating Weld Tip Kit
18065	MACH3 2amp Circuit Breaker
18066	MACH 3 220Volt Phase Control
18067	Universal Vibrator Base/Bowl Replacement Kit
27005	LF TP2 Magnetic Tip (PN type Nails)
27008	MF PGC Ground Clamp & 5ft Cable (for use w/ PBFS14)
27009	A. Heat Sink LF/MFPT/PBFS

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
27010	FG Vibrator Base Rubber Washer
27011	LF1000 Transformer Fibre Spacer
27019	LF2000 Timer
27020	LF1000/2000 Ceramic (New Style)
27029	LF 1/2 Ceramic (Old Style)
27030	LF Black Gun Case
27036	LF Case Screws
27037	LF Line Cord 220Volt
27038	LF Brush
27039	LF Scratch Awl
27041	LF Line Cord-110Volt
27043	LF Micro Switch
27048	LF1000/2000 Case Screws
27050	LF1000/2000 Spring
27051	LF1000/2000 Carrying Case
27053	ES85 PBF Extension Set - 8ft Gun Cable & 5ft Ground Clamp
27054	GEGC PBF Gun Extension - Gun & Switch Cable Only
27055	GECO PBF Ground Extension - Ground Cable Only
27057	PGUME Gun w/ 8ft Cable "For ME Gun Only"
27059	LF 1000/2000 Grommet/Retainer
27061	LF 110 Volt Primary
27063	PGU2 90° Weld Tip Adaptor
27072	LF1000/2000 Electrode W/Braid Short
27080	LF1000/2000LN Electrode
27081	LF1000/2000LN Secondary
27082	CCD-CDMF Foil Weld Tip
27083	CCD-CDMF Standard Weld Tip
27084	CDMF Weld Gun Complete
27085	CDMF Male Cam-Lock Kit
27086	CDMF Ground Clamp Complete
27087	CCD Weld Gun Complete
27088	CCD Ground Clamp Complete
27090	LN Electrode w/ Braid
27091	MF12A Gun or Ground Cable Only-10ft
27092	MF12A Gun Switch Assy-11ft
27093	MF12A Cable & Electrode Assy-10ft
27094	MF12A Transformer 220 Volt
27095	MF12A Ground Clamp Assy-10ft
27096	MF/PBF Gun Cable Assy-10ft
27097	MF12A Oval Grip Handle
27098	MF12A Case Body
27146	A. BBT Buck & Boost
27159	LF TPL2 Magnetic Tip (LN type Nails)
27161	DOL Line Cord 110 Volt
27162	DOL Trigger Switch
27163	DOL Spring
27164	DOL TP3 Magnetic Tip (LN type Nails)
27165	DOL Ceramic
27166	DOL D-Ring
27172	DOL Timer 110 Volt
27173	DOL Timer 220 Volt

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
27178	DOL Line Cord 220 Volt
27205	PBFS Front Panel
27206	PBFS Case
27210	PBFS Base
27211	PBFS Wheels
27213	PBFS/MF Flush Mount Camlock
27216	PBFS Handle
27217	PBF/MF Line Cord w/Strain Relief
27218	PBFS Clamp & Bolts
27220	PBFS Terminal Block MT Bracket
27222	PBFS Lower Copper Crossover
27223	PBFS Back Panel
27224	PBFS Back Panel Washer
27225	PBFS Back Panel Bolt
27230	MF/PBF TP9 Weld Tip Kit (replaces the TP8)
27231	MFPT/PBFS Electrode Assembly
27232	MFPT Gun Cable Only 6ft-6in
27233	MFPT/PBFS Switch Cable Only
27234	PBFS Gun Cable Only 8ft
27236	PBFS Fibre Sleeve
27237	PBFS 4in Electrode
27238	PBFS Roll Pin
27239	PBFS Case For Gun
27240	PBFS Case Screws
27241	PBFS Gun Switch Assembly
27243	PBFS Cable & Electrode Assembly
27244	PBFS Brass Jack
27245	MFPT/PBFS Gun Switch
27246	MFPT Gun Case
27247	MFPT Switch Wire Assembly
27248	MFPT Gun Cable/Electrode
27249	MFPT Case Cover
27250	MFPT Case Body
27251	MFPT Switch Wire Strain Relief
27252	MFPT Gun Cable Strain Relief
27253	MFPT Power Cable Strain Relief
27255	MFPT 10 Post Terminal Block
27256	MFPT Aluminum Connector Block
27257	MFPT Clamp & Nuts
27315	24Volt Green Light
27316	MF/PBF Red Status Light
27317	MF/PBF Amber Power Light
27318	MF12 Case Top Cover w/ Handle
27319	MF12 Case Body
27320	MF12 Case Side Panel
27321	MF12 Front Handle
27322	MF12 Top Handle
27323	MF12 Rear Handle
27326	MF12 Weld Potentiometer Knob
27327	PBF510 Front Panel
27328	PBF510 Side Panel - RIGHT



## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
27329	PBF510 Side Panel - LEFT
27330	PBF510 Back Panel
27331	PBF510 Storage Bin
27332	PBF510 Transformer Mounting Bracket
27333	PBF510 Chassis
27334	PBF510 Lower Chassis Cover
27335	PBF510 Wheel - Rear
27336	PBF510 Wheel - Casting
27337	PBF510 Component Mounting Bracket
27338	PBF510 Switch Wire Assembly
27339	PBF510 Gun Cable Only
27340	PBF510 Ground Cable Only
27341	PBF510 Gun Cable/Electrode
27342	PBF510 Lexan Shield
27343	PBF510/MF12A Socket Cover
27344	PBF PGU510 Gun & 16ft Cable Assembly
27345	PBF PGC510 10ft Ground Cable Assembly
27346	PBF510 Line Cord w/Strain Relief
27347	PBF510 17ft Switch Cable 16-3
27367	MFPT Gun & Cable Assembly
27368	MFPT Ground Clamp Assembly
27376	LF Transformer/Insulator Fish Paper
27396	PBFS Base Large Port
28009	LSB Replacement Blade for LS
28012	LS Cross Cut Assembly
28013	LS Blade w/Hub
28014	LS/LSU Crank Handle
28015	LSS Slitting Assembly w/ Blade Roller for LS
28016	LS4 4ft. Measuring Tape
28017	LS/LSU 5ft. Measuring Tape
28018	LS4 4ft. Liner Spool
28019	LS/LSU 5ft. Liner Spool
28021	LS5 5FT Cross Cut
28023	LS5 5ft. Frame Only
28024	LS Slitter Bracket
28025	LS Slitter Support Casting
28026	LS Blade Hub & Bushing
28027	LS Spring Hold Downs
28028	LS4 4ft. Slitter Drive
28029	LS/LSU 5ft. Slitter Drive
28030	LS/LSU Blade Roller
28031	LS/LSU 12in Octagon Collar
28032	LS4 4ft. Pipe
28033	LS/LSU 5ft. Pipe
28038	LS4 4ft. Drive Roller
28039	LS5 5ft. Drive Roller
28040	LS4 4ft. Idler Roller
28041	LS/LSU 5ft. Idler Roller
28042	LS/LSU Feed Guide
28043	LS Locking Thumb Screw
28047	LS4/5 Cross Cut Hand Grip

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
28058	LS Nylon Roller w/Bolt
28059	LS Nylon Roller Bolt
28060	LS Blade Hub Bolt
28061	LS/PLS/LSU Sandpaper Kit
28062	LSU Cross Cut Blade Hub
28063	LSU Cross Cut Idler Gear
28065	LS 5ft. Frame
28066	LS4/5 Adjustment Knob
28068	LS/LSU 5ft. Feed Shaft
28069	LS/LSU Roller Handle
28070	LS4/5 Sprocket
28071	LS4/5 Chain
28073	LS5 Cross Cut Handle
28077	LSU Cross Cut Assembly (Without Handle)
28078	LSUS Slitter Assembly w/ Blade Roller
28079	LSU Cross Cut Blade w/Gear
28080	LSUB Replacement Single Bevel Blade
28081	LSU Slitter Blade w/Hub
28082	LSU Slitter Blade Hub
28083	LSU Spring Hold Downs
28084	LSU Friction Slide
28085	LSU Locking Knob
28086	LSU Cross Cut Roller
28087	LSU Cross Cut Drive Gear
28088	LSU Cross Cut Rack
28089	LSU Cross Cut Handle
28090	LSU Feed Guide
28091	LS/LSU Hold Down Dog
28092	LSU Roller Drive Gear
28094	LSU Slitter Blade Drive Shaft
28095	LSU Flange Bearing
28096	LSU Drive Chain
28097	LSU Cross Cut Idler Gear
28098	LSU Slitter Drive Gear
28099	LSU Bumper Stop
39001	GBAC Air Sleeve Valve
39003	GBAC Reg Street Elbow
39004	GBAC Reg Male Elbow
39006	GBAC Select Knob Assembly
39007	GBAC Select Knob Shaft
39008	GBAC Select Knob Spring
39009	GBAC Select Knob Retainer
39011	FGMH Console Green Lens
39012	FGMH Console Red Lens
39013	FGMH Console Bulb
39014	FGMH Console Lamp Holder
39015	GBAC Pump Ball (Sandpiper Pump)
39016	GBAC Flange Gasket (Sandpiper Pump)
39017	GBAC Manifold Gasket (Sandpiper Pump)
39018	GBAC Pump Diaphragms (1pr) (Sandpiper Pump)
39019	GBAC ARO Fluid Kit(63711962C)

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
39020	PLS Sending Socket
39022	PLSU2 Reverse/Forward Relay
39032	GBAC 3/4 Valve Assembly Brass
39033	SSF Pick-Up Tube-Short
39034	SSF Pick-Up Tube-Long
39035	SSF Pick-Up Tube Coupler
39036	SSF Long Nipple
39049	Sprayfast - Mini Pump Only
39051	Sprayfast 5/55 Retrofit Flush Kit
39052	SSFU Flush Fitting Assy
39053	SSFU Flush Hose Assy
39054	SSFU Lid w/Labels
39055	HSMH Carriage Brake Solenoid
39056	HSMH Carriage Sled Mounting Plate
39057	HSMH Carriage Sled Mounting Block
39058	HSMH Proximity Switch Bracket
39059	HSMH Cable Track Fixed Bracket
39060	PLS/ASVC Cross Cut Delay Timer
39065	PLS Photo Receiver
39066	PLS Sending Lamp
39067	PLS Sending Shade
39068	Receiving Board
39076	PLS Rolls w/ Bushing
39077	PLS Cradle Side Plate
39078	PLS Cutting Head Assembly
39079	PLS Cradle Leg
39080	PLS Cradle Cross Angle
39082	PLS Corner Brace
39083	PLS Entire Cradle
39084	PLS Roller Plate
39085	PLS Nylon Roller
39087	PLSS Slitter Assembly w/Blade Roller
39090	PLS Cross Cut Interlock
39091	PLS Cross Cut Cylinder
39092	PLS 5ft Cross Cut Cable Replacement Kit (*Need Make & Model #*)
39093	PLSB Replacement Blade
39094	PLS Motor
39095	PLS Speed Reducer L to R or R to L
39096	PLS Clutch
39097	PLS Clutch Control
39098	PLS Drive Gear
39099	PLS Circuit Panel
39100	PLS Drive Chain
39101	PLS Chain Lock Link
39102	PLS Love Joy Coupling
39103	PLS Cross Cut Relay
39106	PLS 24 Volt Transformer
39107	PLS Cross Cut Assembly
39109	PLS Panel Light
39110	PLS Run Switch/MACH Pin Feed Switch
39112	PLS Stop Switch

**DURO DYNE MACHINERY SPARE PARTS LIST PRICING**

PART #	DESCRIPTION
39114	PLS Mode Selector Switch
39116	PLS Pinch Roller Solenoid
39117	PLS Cross Cut Solenoid
39118	PLS Line Cord
39121	PLS Female Rod End Bearing
39122	PLS Angle Iron w/Tape L to R
39123	PLS Angle Iron w/Tape R to L
39124	HSMH 3-Position Ground Block
39125	HSMH 2-Position Ground Block
39126	HSMH Weld Cable Suspension Spring
39127	HSMH Carriage Forward Belt
39128	HSMH Mandrel Ground Bar
39129	HSMH Catwalk Non-Skid Tape
39130	HSMH Catwalk Step Non-Skid Tape
39131	HSMH Conveyor Drive Pulley
39132	HSMH Mandrel Lead-In
39133	PLS Drive Roller
39134	PLS Pinch Roller
39135	PLS Pinch Roller Cylinder (122D)
39136	PLS Pinch Roller Air Regulator
39138	PLS Regulator Bracket
39139	PLS Locking Wheel
39140	PLS Control Module L TO R
39141	PLS Control Cable
39143	PLS Control Module R TO L
39145	HSMH Lower Mandrel Assembly
39146	PLS Pinch Roller Cylinder Bracket(D8315)
39147	HSMH Carriage Cylinder
39148	HSMH Depart Cylinder
39149	HSMH Shock Absorber
39150	HSMH Dwell Solenoid
39151	HSMH Depart Solenoid
39152	HSMH Carriage Solenoid
39153	HSMH Feed Solenoid
39154	HSMH Feed Cylinder Flow Control
39155	HSMH Carriage Cylinder Brake Pad (Pair)
39156	HSMH Material Feed Magnet
39157	HSMH Encoder/Connector Assembly
39158	HSMH Upper Track Side Rails
39159	HSMH Track Sensor
39160	HSMH Track Gate
39161	HSMH Gate Return Spring
39162	HSMH Upper Track Adjustment Rail
39163	HSMH Lower Track Side Rails
39164	HSMH Lower Track Rail Stiffeners
39165	HSMH Lower Track Pin Latch Kit
39166	HSMH Power Bar
39167	HSMH Safety/Override Switch
39168	HSMH Air Hose Assembly-8FT
39169	GBAC 1/2 Valve Assembly Brass
39170	HSMH Weld Cable Assembly-Ground

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
39172	PLS Guard Interlocks w/Cover
39173	PLS Cross Cut Magnet
39174	HSMH Weld Cable Assembly-Head
39176	GBAC Motor Side Cover
39177	GBAC Feed Cover
39178	GBAC Trough R to L
39179	GBAC Trough L to R
39180	FGMH6 Conveyor System
39181	FGMH5 Conveyor System
39182	FGMH 208/220 Boost Transformers
39183	HSMH Aux Air Header Pressure Gage
39184	HSMH 250K Potentiometer
39185	HSMH Emergency Stop Switch
39186	HSMH Control Console Head Switch
39187	HSMH Weld Timer Potentiometer
39188	HSMH Dwell Timer Potentiometer
39189	HSMH 28V Power Lamp - RED
39190	HSMH 28V Indicator Lamp - AMBER
39191	HSMH 5AMP Circuit Breaker
39192	HSMH 8AMP Circuit Breaker
39193	HSMH 100AMP Circuit Breaker
39194	HSMH 24V Contactor
39195	HSMH Conveyor Support Magnet
39196	HSMH 220V Vibrator Female Power Cord
39197	GBAC Brass Multiport Valve
39201	GBAC Transmission Gear
39202	GBAC Transmission Sprocket
39205	GBAC Drive Chain
39206	GBAC Pinion Gear
39207	GBAC Rack
39208	GBAC Adhesive Chain
39209	GBAC Metering Bracket
39210	GBAC Locking Wheel
39211	GBAC Metering Base Assembly
39212	GBAC Metering Shaft
39213	GBAC Metering Bar Assembly
39214	GBAC Metering Blade
39215	GBAC Blade Retainer
39216	GBAC Mitre Gear
39217	GBAC Metering Bushing
39218	GBAC Metering Collar
39219	GBAC Sleeve Joint
39220	GBAC Speed Reducer R to L
39225	GBAC Pinion Shaft Collar
39226	GBAC Pinion Shaft
39227	GBAC Drive Roller
39228	GBAC Adhesive Roller
39229	GBAC/PLS Leveling Feet
39230	GBAC Universal
39231	GBAC Top Cover
39232	GBAC Frame

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
39233	GBAC Operator Side Panel
39236	GBAC Metering Wheel
39237	GBAC Adjustment Knob
39238	GBAC Adjustment Handle
39239	GBAC Valve Function Chart
39240	GBAC Regulator Bracket
39242	GBAC Tank Cover
39243	GBAC Storage Tank
39244	GBAC Exit Rack
39245	GBAC 10 Exit Finger Cover
39246	GBAC 10 Exit Finger Tips Yellow
39247	GBAC Pump (ARO)
39252	GBAC Complete Plumbing Assembly 1/2 & 3/4
39253	PLS Roll End Bushing w/ Screw
39254	PLS Nylon Cradle Roll End Insert
39258	GBAC Speed Reducer L To R
39259	FGMH Carriage Solenoid Assembly
39260	GBAC Connecting Rod R to L 1/2 X 57 1/2
39261	GBAC Connecting Rod L to R 1/2 X 59 1/2
39262	GBAC Pillow Block
39263	FGMH Dwell Micro Switch
39265	FGMH Track Casting Assembly
39266	FGMH Carriage Bearings
39268	PLS Plex Receiver Cover
39269	GBAC Plumbing Access Kit 55 Gallon
39270	FGMH Conveyor Tension Kit
39271	A. Flat Pillow Block(GBAC & PLS)
39272	GBAC Trough Strainer
39273	HSMH Vibrator Base Plate
39277	FGMH Hold Down Cylinder Wheel-173DZ
39282	FGMH Hold Down Solenoid
39283	FGMH Vibrator Control Box
39290	FGMH Conveyor Pillow Block
39291	FGMH Solid State Weld Relay
39292	MH/HS5 Solid State Weld Relay Assembly
39293	FGMH 2in Pin Delay Timer Kit
39294	MH Track Sensor Replacement Kit
39295	MH/HS6 Solid State Weld Relay Assembly
39296	HSMH Vibrator Bowl Assembly
39297	HSMH 110V Vibrator Base w/Cord
39298	HSMH 220V Vibrator Base w/Cord
39299	HSMH Conveyor Belting
39301	FGMH Console
39306	FGMH Head Switch
39307	FGMH Test Switch
39311	FGMH Weld Potentiometer
39312	FGMH Dwell Potentiometer
39316	FGMH Terminal Block
39319	FGMH 220 Safety Switch
39320	FGMH FGMH 440 Safety Switch
39321	FGMH 440/220 Step Down Transformer

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
39322	FGMH Air Header Assembly
39323	FGMH Air Header
39324	FGMH Feed Solenoid Old Style
39325	FGMH Dwell Solenoid Old Style
39329	FGMH Carriage Flow Control
39333	FGMH 3in Dwell Cylinder
39338	FGMH Tip Retainer Block
39339	FGMH Power Supply Bar
39343	FGMH Micro Switch Bracket
39344	FGMH Micro Switch
39352	FGMH Track Slide Rails
39353	FGMH/RH/FG Anti-Friction Strip
39354	FGMH Quick Exhaust Bracket
39359	Feed Channel Spacer
39363	FGMH Head Mounting Plate
39369	FGMH Vibrator Base
39371	FGMH Ground Bar
39372	FGMH Weld Cable (Old Style)
39374	FGMH Lower Mandrel Assembly
39375	FGMH Mandrel Only
39376	FGMH Mandrel Copper Helpers
39377	FGMH Mandrel Clamps
39383	FGMH Carriage Cylinder Mount
39386	FGMH Carriage Cylinder (D19883-A-4)
39395	FGMH Conveyor Support
39396	FGMH Conveyor Belting
39398	FGMH Conveyor Pulley
40001	PLSU2 Drive Cable Tension Spring
40002	PLSU2 Cross Cut Blade w/Hub
40003	PLSU2 Cross Cut Hub w/ Bushing
40004	PLSU Cross Cut Blade Drive Cable
40100	Air Hose 3/8in Green
40101	Air Hose 3/8in Yellow
40102	Air Hose 3/8in Blue
40103	Air Hose 3/8in Red
40104	Air Hose 1/4in Green
40105	Air Hose 1/4in Yellow
40106	Air Hose 1/4in Blue
40107	Air Hose 1/4in Red
40310	FGMH 110 Volt Plug In Relay
40311	FGMH Vibrator Socket Assembly-Green
40323	FGMH Pin Feed Switch Assembly
40324	FGMH Feed Solenoid New
40325	FGMH Dwell Solenoid New
40328	FGMH Solenoid Only
40371	FGMH Weld Cable Clamp
40372	FGMH Weld Cable (New Style)
40373	FGMH Roto Pulsr Cble Assy-40ft
40386	FGMH Carriage Forward Cylinder (DM150)
40388	FGMH Roto Pulsr 716HV (New Style)
40389	FGMH Roto Pulsr Coupling

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
40390	FGMH Limit Switch
40391	FGMH Roto Pulser 711
40392	FGMH Roto Pulser 716S (Old Style)
40393	FGMH Carriage Forward Pancake Brake Cylinder (AA521-X)
40394	FGMH Return Cylinder (0924DX)
40395	FGMH Brake Pad (1 pr)
40396	FGMH Roto Pulser 15IN Wheel
40397	FGMH Return Solenoid
41003	GN 44108 Drive Cylinder (123DP/D48568)
41006	GN Vibrator Speed Control
41007	GN Button Valve 3P 44106
41010	GN 41PP Valve 44103
41011	GN 34AS Reset Valve 44105
41013	GN Drive Valve 250A 44115
41014	GN Press Valve 125A 44118
41018	GN Back Press Regulator 44116
41021	GN Drive Switch Bracket 30116
41024	GN Drive Cylinder Bracket 44111
41029	GN V Block 30125
41030	GN Track Sensor Input 30110
41031	GN Track Sensor Output 30111
41036	GN Cylinder Stud 3/8-24 x 7/16-20
43004	FDCC2 Conversion Kit
43007	DWD1 Guide Hub Set
43012	WVDL1234A 48in Extension Kit to Accommodate up to 6ft Conduit
43014	ASCV2 2in Cutting Blade
43015	ASCV2 Main Cylinder
43016	ASCV2 Solenoid Assembly
43017	ASCV2 2in Blade Saddle
43018	ASCV2 Initiate Switch
44001	FG/RH MACH Vibrator Sensor Cord - Old Style
44002	FG/RH MACH Vibrator Sensor - Old Style
44003	FG/RH MACH Vibrator Sensor Bracket - Old Style
44006	FG/RH MACH Vibrator Socket Guard
44007	MACH I/II 1amp Circuit Breaker
44010	FG MACH Lower Track Casting
44014	FG/RH MACH Feed Solenoid
44015	FG MACH II/III Dwell Solenoid Assy
44016	FG MACH Power Bar
44017	FG MACH Weld Cable
44018	FG MACH Weld Cable Retainer
44019	FG MACH Weld Cable Camlock
44020	FG MACH Head Terminal Strip
44021	FG MACH Head Mounting Plate
44022	FG MACH Lower Ground Bar
44023	FG MACH Control Module
44024	FG/RH MACH Mian Power Switch
44025	FG/RH MACH LCD Display
44026	MACH I&II Weld Potentiometer
44027	MACH/FPP Weld Potentiometer Knob
44029	FG/RH MACH Relay Select Switch



## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
44030	FG/RH MACH Trouble Display
44031	FG/RH MACH Vibrator Potentiometer
44032	FG/RH MACH Vibrator Lamp
44033	MACH/FPP Power Switch
44034	FG/RH MACH Weld Lamp
44035	FG MACH I Power Pack
44037	FG/RH MACH Power Pack Cover
44041	MACH II Line Cord w/Strain Relief
44042	FG/PBF/RH MACH II Cord Strain Relief
44043	FG MACH Dwell Cover
44044	FG MACH Feed Cover
44045	FG MACH Weld Cable Guard
44046	FG MACH Component Module
44047	Power Contactor
44048	FG MACH HI Volt Terminal Strip
44052	FG/RH MACH 12 Volt DC Power Supply
44055	RH MACH Lower Track Casting
44056	Universal Insulated Bracket B
44057	Universal Insulated Bracket A
44059	RH MACH Power Bar
44060	RH MACH Short Weld Cable
44061	RH MACH Female Camlock
44062	RH MACH Trolley Mount Plate
44063	RH MACH Lower Ground Bar
44064	RH MACH Weld Cable Retainer
44065	RH MACH Control Module
44066	RH MACH Power Pack
44067	RH MACH Flex Wire Mold
44068	RH MACH Rubber Air Hose
44070	RH MACH Weld Cable Camlock
44071	RH MACH Feed Cover
44072	RH MACH Component Module
44073	RH MACH HI Volt Terminal Strip
44075	RH MACH Trolley
44076	RH MACH Trolley Cover
44077	RH MACH Weld Potentiometer
44080	RH MACH Power Bar Bracket
44081	RH MACH Actuator Mount Plate
44082	RH MACH Bearing Mount Plate
44083	RH MACH Lock Knob Spring
44084	RH MACH Lock Knob Catch
44085	RH MACH Pin Release
44086	RH MACH Pin Release Spring
44087	RH MACH Pin Release Stop
44088	RH MACH Flex Link
44089	RH MACH Long Weld Cable
44090	FG/RH MACH Vibrator Control Relay Board Assembly
44091	Universal 24Volt Multi-Tap Transformer
44092	FG MACH I Dwell Solenoid
44094	FG/RH MACH Track Sensor Replacement Kit
44095	MACH I & II FGMH Track Sensor

## DURO DYNE MACHINERY SPARE PARTS LIST PRICING

PART #	DESCRIPTION
44096	FG/RH MACH Weld Relay/Insulator
44097	FG/RH/FGMH Solid State Vibrator Control Relay
44098	RH MACH Floating Weld Cable Only
44099	RH MACH Floating Weld Cable Kit
44100	FG MACH Weld Cable Spring Guard Kit
44101	HS/507/MACH3 7KVA Transformer
44102	FG3 9in Dwell Cylinder
44103	FG3 Upper Track Siderails-Short
44104	FG3 Upper Track Siderails-Long
44105	FG3 Power Pack Enclosure
44106	FG3 Power Pack Cover
44107	FG3 Dwell Cylinder Guard
44108	FG3 Feed Cylinder Guard
44109	FG3 Control Module
44110	FG3 Head Mounting Plate
44111	FG3 Weld Cable-Short
44112	FG3 Weld Cable-Long
44113	FG3 Component Module
44114	FG3 Vibrator Cord Strain Relief
44115	FG3 Terminal Strip-High Voltage
44116	FG3 Dwell Solenoid Assembly
44117	RH3 Component Module
44118	RH3 Trolley
44119	RH3 Trolley Cover
44120	RH3 Short Weld Cable
44121	RH3 Control Module
44122	RH3 Trolley Mount Plate
44123	MH507 Head Weld Cable
44124	MH507 Ground Weld Cable
44125	MH507 2amp 250V Fuse
44126	MH507 Encoder Conn Assy 300
44127	Universal Vibrator Line Cord Kit
44128	MH507/HSMH Encoder Spring