


WVDL-1234A Rod-Loc Machine Assembly and Operation Guide

Assembly Instructions: (For Operator Safety)

- 1)- Without Extension: The Rod-Loc Machine should be secured to a flat working surface using the Mounting Brackets supplied. Attach the Mounting Brackets using the Spring T-Nuts, Short Cap Screws and Washers.
- 2)- With Extension: The Rod-Loc Machine should be secured to a flat working surface using the Mounting Brackets supplied. Attach the Mounting Brackets to the Rod-Loc Machine and the Extension using the Long Hex Head Bolts, Washers and Nuts.
- 3)- For operator safety: Secure the Rod-Loc Machine to the flat working surface using the Short Hex Head Bolts, Washers and Nuts supplied.


Instructions for use: (NOTE: The Rod-Loc Machine is shipped with all of the Conduit Mounting Blocks installed)

- 1)- To set-up the Conduit Mounting Blocks: Remove the End Block first by loosening but NOT removing the Locking Screws. Pull the Locking Pin up and Slide the End Block out. Loosen but DO NOT remove the screws on the Conduit Mounting Blocks to slide them out; set the appropriate Conduit Mounting Blocks as needed for either 1/2" or 3/4" Conduit. Slide the End Block back on to match the conduit length as shown below (ensure the Locking Pin is properly set in a Mounting Hole then secure the Locking Knob). The T-Handle Hex Key can be used for all screws. Position the Conduit Mounting Blocks at each end as shown in the reference dimensions and center the one in the middle.
- 2)- Ensure the Gauge of the Air Regulator is set to 70 PSI (minimum).
- 3)- Depress the On/Off Switch to activate the Rod-Loc Machine and insert the Nuts securely.





WVDL-1234A Rod-Loc Machine Replacement Parts List & Locations




Please contact our Technical Service Department with any questions at - Ph: 631-249-9000 / Fax: 631-249-8346



WVDL-1234A Rod-Loc Machine Wiring Diagram

LATEST: 2-27-18/A275-01-36



Please contact our Technical Service Department with any questions at - Ph: 631-249-9000 / Fax: 631-249-8346